

Sick ATM60 profibus. Opvolger Sick , testen , instellingen

ATM60 voor profibus is uitgefaseerd. Opvolger:



ATM60-P4H13X13

Artikelnummer:
1030013



A3M60A-S4PB014x17

Artikelnummer:
1053341



Aansluiting

Bus-adapter

Stekker, Contactdoos

Aansluitrichting

-

Axiaal

Aantal omwentelingen

8192 (13 bit)

131072 (17 bit)

Aantal polen

-

5-pins

Aantal stappen per omwenteling

8192 (13 bit)

16384 (14 bit)

Asdiameter

10 mm

10 mm

Aslengte

19 mm

19 mm

Bedrijfstemperatuurbereik

-20 °C ... 85 °C


-30 °C ... 80 °C

Certificaat

EU declaration of conformity, UK declaration of conformity, ACMA declaration of conformity, MAR declaration of conformity, China-RoHS, cULus-certificaat

EU declaration of conformity, UK declaration of conformity, ACMA declaration of conformity, MAR declaration of conformity, China-RoHS, cULus-certificaat

Voor testen heb ik het project van de SBA kraan van Huisman genomen:



We focussen ons op encoders 33 en 34. Dus voor de vorken SD en DD

Om de nieuwe encoder toe te kunnen voegen moeten we van de Sick website de GSD file downloaden:



Sensor Intelligence.

[Producten](#) [Oplossingen](#) [Support](#) [Focus](#) [Bedrijf](#)

[Thuis](#) > [Producten](#) > [Motion-Control-sensoren](#) > [Absolute encoders](#) > [A3M60](#) > [A3M60A-S4PB014x17](#)

Absolute encoders: A3M60

A3M60A-S4PB014x17

[Documentatie \(13\)](#) **[Software \(1\)](#)** [Certificaten \(6\)](#) [CAD \(1\)](#)

[Alle filters](#)

1 Resultaten

| Software | Versie | Ondersteunde producten | Maat | |
|---|--------|------------------------|------|---|
| Software GSD-bestand (A3M60A) | | A3M60 | 6 KB | Download SHA-256 |


Ondersteunde producten: A3M60
Ondersteund productsegmenten: Absolute encoders

Daarna de GSD toevoegen in de Siemens hardware manager:

4.4.1 Loading the GSD file (once only)

- Open the hardware manager for your PLC.

Fig. 5: Hardware manager in the SIMATIC



- Install the GSD file STEG0COA.gsd for the A3M60 Advanced using the **Options** menu, **Install GSD file... command**


You will find the GSD file on the Internet at <http://www.sick.com>.

The A3M60 Advanced appears in **Additional Field Devices**.

HW aansluitingen device:

4.2.1 Connections of the A3M60 Advanced

Fig. 3: Connections of the A3M60 Advanced



Tab. 29: Pin assignment for the connection of the voltage supply

| Pin | Signal | Core color ⁹⁾ | Function |
|-----|----------------|--------------------------|---------------------------------|
| 1 | V _S | Brown | Supply voltage 10 V ... 32 V DC |
| 2 | - | White | Do not use |
| 3 | GND | Blue | 0 V DC (ground) |
| 4 | - | Black | Do not use |
| 5 | - | Grey | Not assigned |

Tab. 30: Pin assignment for the connection PROFIBUS IN

| Pin | Signal | Core color ⁹⁾ | Function |
|-----|--------|--------------------------|--------------------|
| 1 | - | - | Not assigned |
| 2 | A | Green | A-wire PROFIBUS DP |
| 3 | - | - | Not assigned |
| 4 | B | Red | B-wire PROFIBUS DP |
| 5 | Screen | - | Housing |

Tab. 31: Pin assignment for the connection PROFIBUS OUT

| Pin | Signal | Core color ⁹⁾ | Function |
|-----|--------|--------------------------|--------------------|
| 1 | - | - | Not assigned |
| 2 | A | Green | A-wire PROFIBUS DP |
| 3 | 0 V DC | - | Ground |
| 4 | B | Red | B-wire PROFIBUS DP |
| 5 | Screen | - | Housing |

- Notes**
- ▶ **Connect the screen to the encoder's housing!**
 - ▶ Observe the maximum cable lengths (see Tab. 3 on page 10).

⁹⁾ On the usage of pre-wired cables.


instellen profibus adres:

A3M60 Advanced

There are the following controls under the screw cover:

- rotary switch for addressing (address 1-125)
- preset pushbutton
- **DIP switch for bus termination (termination)**

Fig. 2: Position of the controls



4.3.1 Bus termination

At the start and end of each segment, the bus must be terminated using a terminator. The A3M60 Advanced PROFIBUS Absolute Encoder contains bus termination that can be enabled.

The bus can be terminated using the DIP switches.

- ▶ To terminate the bus, set both DIP switches to ON.
- ▶ Alternatively you can use an external terminator (see section 7.2 “Accessories” on page 43).

4.3.2 Addressing

Each device in the bus segment must have a unique address. Each address is only allowed to occur once in the bus segment. The A3M60 Advanced PROFIBUS Absolute Encoder is factory set to address 2. The highest address that is allowed to be set is 125.

To set the address use the hex rotary switch and the decimal rotary switch.

- ▶ Set the decades for the address using the hex rotary switch.
- ▶ Set the units for the address using the decimal rotary switch.

Examples

| Address | Hex rotary switch | Decimal rotary switch |
|---------|-------------------------------|-----------------------|
| 17 | 1 | 7 |
| 123 | C (corresponds to decimal 12) | 3 |

met bovenstaande gegevens kunnen we verder.

Voor de test heb ik de hardware config aangepast. Alle andere HW eruit, alleen de 33, een bestaande ATM60 erin , en op adres 34 voegen we nieuwe encoder in:

HW Config - [SIMATIC 400 (Configuration) -- Huisman SBA_kantoorTest]

Station Edit Insert PLC View Options Window Help

| Slot | DP ID | ... | Order Number / Designation | I Address | Q Address | Comment |
|------|-------|-----|-----------------------------|-----------|-----------|---------|
| 1 | 24X | | IO_04 (IN_04) + PRESET-Wert | 132...135 | 132...135 | |

Als de GSD file is toegevoegd, kun je zoeken op AxM:

HW Config - [SIMATIC 400 (Configuration) -- Huisman SBA_kantoorTest]

Station Edit Insert PLC View Options Window Help

Eind: AxM
Profile: Standard

PROFIBUS DP

- Additional Field Devices
 - General
 - Drives
 - Switching Devices
 - I/O
 - Encoders
 - Leuze
 - SICK
 - AxM Encoder - ADV 1.01, Class-4
 - Universal module
 - Tel. 81
 - Tel. 83
 - Tel. IO-04
 - Tel. IO-08
- AG-626 DP_V2.0_
 - AG626DP
 - AG626DP
 - ATM 60-P... V2.0
 - DME 3000-111P
 - OLM200

| Slot | DP ID | ... | Order Number / Designation | I Address | Q Address | Comment |
|------|-------|-----|-----------------------------|-----------|-----------|---------|
| 1 | 24X | | IO_04 (IN_04) + PRESET-Wert | 132...135 | 132...135 | |

Sleep de encoderoep de profibus lijn, en dan zal deze in de config opgenomen worden:

HW Config - [SIMATIC 400 (Configuration) -- Huisman SBA_kantoorTest]

Station Edit Insert PLC View Options Window Help

Find: AxM
Profile: Standard

PROFIBUS DP

- Additional Field Devices
 - General
 - Drives
 - Switching Devices
 - I/O
 - Encoders
 - Leuze
 - SICK
 - AxM Encoder - ADV 1.01, Class-4
 - Universal module
 - Tel. 81
 - Tel. 83
 - Tel. IO-04
 - Tel. IO-08

- AG-626 DP_V2.0_
- AG626DP
- AG626DP
- ATM 60-P... V2.0

(35) AxM Encoder - ADV 1.01.

| Slot | DP ID | Order Number / Designation | I Address | Q Address | Comment |
|------|-------|----------------------------|-----------|-----------|---------|
| 1 | | | | | |

Slot 1 is nog leeg. Je moet dan "Tel IO-04" hierin slepen:

(35) AxM Encoder - ADV 1.01.

| Slot | DP ID | Order Number / Designation | I Address | Q Address | Comment |
|------|-------|----------------------------|-----------|-----------|---------|
| 1 | 195 | Tel. IO-04 | 512...515 | 512...515 | |

Vergelijk je dit met de bestaande ATM60:

HW Config - [SIMATIC 400 (Configuration) -- Huisman SBA_kantoorTest]

Station Edit Insert PLC View Options Window Help


PROFIBUS: DP master system

(33) ATM 60-P... V2.0

| Slot | DP ID | Order Number / Designation | I Address | Q Address | Comment |
|------|-------|-----------------------------|-----------|-----------|---------|
| 1 | 2AX | IO_04 (IN_04) + PRESET-Wert | 132...135 | 132...135 | |

Navraag bij Sick gedaan. IO-04 ,bij de ATM60 komt overeen met de Tel.IO-04 bij de nieuwe encoder.
 Dan is al het telegram verkeer gelijk.

dus voor de test is de encoder voorzien van adres 34, input/output op woorden 136-139



| Slot | DP ID | Order Number / Designation | I Address | Q Address | Comment |
|------|-------|----------------------------|-----------|-----------|---------|
| 1 | 195 | Tel. IO-04 | 136...139 | 136...139 | |

in de encoder zelf zijn ook een aantal instellingen:

ATM60:

AxM encoder:

Checken we de originele code dan zien we dat in OB35 NW11 en 12 de de SD en DD encoder worden aangeropen op PID132 en PID136.

De nieuwe encoder moet op counterclockwise staan als de ATM60 op clockwise staan om de waarden dezelfde kant op te laten gaan. Dit is te zien al bij de ruwe waarde. Vreemd.